


Fig 1.1: Minimum package contents for the Four of Diamonds PC Card



Carefully inspect the contents of the box (pictured below) to ensure that everything you should have is included (minimum equipment shown), and that nothing has been damaged during shipment. Retain the packing material in case the unit needs to be returned for service.

## Unpack the Four of Diamonds PC Card



- **Advanced Power Management** – When not in use, the Four of Diamonds PC Card powers down automatically. This feature conserves battery power and extends the life of your PC Card and computer.
- **10BaseT and 10Base2 Auto-negotiation** – The Four of Diamonds PC Card automatically detects the network type to which it is connected and configures itself accordingly.

### Four of Diamonds PC Card QuickNotes


For further information, consult the Manuals and Documentation found on the Ositech CD-ROM (accessible through Ositech's Fastmenu, autolaunched when the CD is inserted).

- Connect to either a 10BaseT or 10Base2 Ethernet network port.
- Install the Four of Diamonds PC Card software.

This guide explains how to:

### About this Guide

## QuickStart Guide



## 2

## Installing the Four of Diamonds PC Card

This section includes software installation instructions for Windows 2000, Windows Me, Windows 98, Windows 95 and Windows NT 4.0 operating systems. For all other operating systems, refer to the **Readme.txt** file on the *Ositech CD-ROM*.

If you do not have a CD-ROM drive on your laptop, use a desktop computer with a CD-ROM drive and a floppy drive to create an installation diskette. This can be done from the Ositech Fastmenu found on the CD-ROM. Once you have an installation diskette created, follow the steps below using the diskette instead of the CD-ROM.

Determine which operating system you are running and follow the appropriate procedure.

### Windows 2000

This section describes how to install the Four of Diamonds PC Card in the Windows 2000 operating system.

To install the Four of Diamonds PC Card in Windows 2000:

- 1 - Insert the Ositech CD into your CD-ROM drive. The Ositech Fastmenu Program should launch automatically (see *fig 2.1*).
- 2 - Before inserting your Four of Diamonds PC Card, run **SETUP2K.EXE** from the button on the Ositech Menu. (If the menu program did NOT launch automatically, please run the **SETUP2K.EXE** program from the root of the Ositech CD).
- 3 - Insert your Four of Diamonds PC Card into an available PCMCIA card slot (ensure the Ositech CD is still in your CD-ROM drive).



fig 2.1: The Ositech Menu.

- 4 - Windows will identify new hardware and begin instal-

lation. A screen will open displaying the message "Digital Signature Not Found" message. This is normal. Simply click **Yes** to continue the installation of your Four of Diamonds PC Card (see *fig 2.2*).

- 6 - Your Four of Diamonds is now installed. Contact your Network Administrator to configure your local LAN/Ethernet connections. You will need to restart your PC after this is set up.




fig 2.2: Windows will display the *Digital Signature Not Found* screen. This is normal. Click Yes to continue.



Copyright © 2000 Ositech Communications Inc., Guelph, Ontario, Canada and its licensors. All rights reserved. Ositech Communications Inc. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance or use of this material. Trumpcard is a registered trademark, and Four of Diamonds, DPI, and Digital Phone Interface are trademarks of Ositech Communications Inc. Other names are trademarks of their respective companies. Information in this document is subject to change without notice. Printed in Canada.

**OSITECH**



Be MOBILE! Be CONNECTED!

### Copyright


679 Southgate Drive, Guelph, Ontario, Canada N1G 4S2  
Toll Free: 888-OSITECH (674-8324)  
Local Telephone: (519) 836-8063  
Facsimile: (519) 836-6156  
Internet: http://www.ositech.com  
FTP: ftp.ositech.com  
support@ositech.com  
sales@ositech.com

### How To Contact Us

For further instructions, or in case of problems while installing your Four of Diamonds PC Card, please consult the online manual found on the Ositech CD (and accessible from the Ositech Menu). You can also download PDF versions of the manuals from Ositech's website at [www.ositech.com](http://www.ositech.com). For any further problems or concerns, please contact Ositech directly.

### Online Manuals

- 1 Plug the direct-connect Ethernet cable into the Four of Diamonds PC Card socket labeled *Ethernet*.
  - 2 Plug the RJ-45 connector into a network port.
- Caution – The PC Card connector is keyed to go in one way only. If you feel resistance before the PC Card connector is inserted fully, remove the connector, turn it over (silver tongue up) and re-insert it.**



## Connect to an Ethernet Network



### Windows Me

This section describes how to install the Four of Diamonds PC Card in the Windows Me operating system.

To install the Four of Diamonds PC Card in Windows Me:

- 1 - Insert the Ositech CD into your CD-ROM drive. The Ositech Fastmenu Program should launch automatically. You can close the menu program, as it is not required for installation from the CD-ROM. The menu (which can be launched later) contains manuals, registration information and links to the Ositech website. It will be of use to you later.
- 2 - Insert your Four of Diamonds PC Card (ensure the CD is in the CD-ROM drive)
- 3 - Windows will detect new hardware (see *fig 2.3*).



fig 2.3: Windows will detect your Seven of Diamonds. Click *Next* to do an *Automatic search for a better driver*.

- 4 - Windows will ask if you would like to do an *Automatic search for a better driver (Recommended)*. Click **Yes** to continue. Windows will install your Four of Diamonds PC Card without any further user intervention.
- 5 - Your Four of Diamonds is now installed. Contact your Network Administrator to configure your local LAN/Ethernet connections. You will need to restart your PC after this is set up.

### Windows 98

This section describes how to install the Four of Diamonds PC Card in the Windows 98 operating system.

To install the Four of Diamonds PC Card in Windows 98:

- 1 - Insert the Ositech CD into your CD-ROM drive. The Ositech Menu Program should launch automatically. You can close the menu program, as it is not required for installation from the CD-ROM. The menu (which can be launched later) contains manuals, registration information and links to the Ositech website. It will be of use to you later.

- 2 - Insert your Four of Diamonds PC Card (ensure the CD is in the CD-ROM drive)
- 3 - Windows will detect new hardware (your Four of Diamonds PC Card).
- 4 - Windows will ask if you would like to *Search for the best driver for your device (recommended)*. Choose this option and click *Next*.



fig 2.4: Ensure the check box for the CD-ROM is selected and click *Next*.

- 5 - Windows will ask you to point the installation Wizard to the proper location for the Four of Diamonds drivers. Ensure the check box for the CD-ROM is selected as the location to search for drivers and click *Next* (see fig 2.4).
- 6 - Windows will display the *Updated driver (Recommended)* that it has found for your Four of Diamonds and ask you if it is the correct driver. Ensure the recommended driver is checked and click *Next* to continue.



fig 2.5: Point Windows to the Ositech CD to find the file **OTCETH4 . SYS**.

- 7 - Windows will begin installing the proper files. While installing these files, Windows will prompt you to insert the Ositech Driver Disc (this is referring to the Ositech CD-ROM), and you will be asked for the location of the **OTCETH4 . SYS** file. Direct Windows to the CD-ROM drive (and the Ositech CD) for this file, and click *OK* (see fig 2.5).
- 8 - Your Four of Diamonds is now installed. Contact your Network Administrator to configure your local LAN/Ethernet connections. You will need to restart your PC after this is set up

## Windows 95

This section describes how to install the Four of Diamonds PC Card in the Windows 95 operating system.

To install the Four of Diamonds PC Card in Windows 95:

- 1 - Insert the Ositech CD into your CD-ROM drive. The Ositech Menu Program should launch automatically. You can close the menu program, as it is not required for installation from the CD-ROM. The menu (which can be launched later) contains manuals, registration information and links to the Ositech website. It will be of use to you later.
- 2 - Insert your Four of Diamonds PC Card (ensure the CD is in the CD-ROM drive).
- 3 - Windows will detect your Four of Diamonds PC Card.



fig 2.6: Windows finds updated drivers for your Four of Diamonds. Click *Finish* to install them.

- 4 - Windows will find Updated drivers for this device. Click *Finish* to install them (see fig 2.6).
- 5 - The *Network* window will open. Contact your Network Administrator regarding the correct settings for use on your network. Click *Close* when finished (see fig 2.7).




fig 2.7: The Network window will open, contact your Network Administrator for the proper settings for your machine..

- 6 - Windows will begin installing the proper files. While installing these files, Windows will prompt you to insert the Ositech Driver Disc (this is referring to the Ositech CD-ROM), and you will be asked for the location of the **OTCETH4 . SYS** file (see fig 2.8).



fig 2.8: Direct Windows to the Ositech CD to find **OTCETH4 . SYS**.

- 7 - Point Windows to the CD-ROM drive for this file, and click *OK*.
- 8 - If Windows requests networking system files (such as **netapi .dll**, see diagram at right) - point Windows to your CABS files folder or your Windows CD-ROM.
- 9 - Your Four of Diamonds is now installed. Contact your Network Administrator to configure your local LAN/Ethernet connections. You will need to restart your PC after this is set up




fig 2.9: Direct Windows to your Windows CD or your CABS files folder.

## Windows NT 4.0

To install the Four of Diamonds PC Card in Windows NT 4.0:

**Note – Ensure the Four of Diamonds PC Card is inserted into a PCMCIA slot BEFORE you turn your computer on.**

- 1 - Insert the Ositech CD into your CD-ROM drive.
- 2 - From the Start>Settings menu, select Control Panel.
- 3 - Double-click the Network icon. The Network Window opens.
- 4 - If networking support is not installed, NT will install it automatically now.
- 5 - Click the *Adapters* Tab (see fig 2.10).
- 6 - Click the *Add* button.
- 7 - The *Select Network Adapters* window will open. Click *Have Disk* (see fig 2.11).




fig 2.10: In the *Network* window, click the *Adapters* tab.




fig 2.11: In the *Select Network Adapter* window, click *Have Disk...*

- 8 - Point the installer to the CD-ROM drive.
- 9 - Click *OK* to continue.
- 10 - From the list (see fig 2.12), select your *Four of Diamonds 10 Mbps Trumpcard* and click *OK*.
- 11 - The Ositech Trumpcard Configuration Screen appears.
- 12 - Choose resources that are available on your machine.  
**NOTE: THE DEFAULT RESOURCES (as shown below, in fig 2.13) MAY NOT BE AVAILABLE ON YOUR MACHINE.** Contact your Network Administrator for complete details and system settings. Click *Continue* when done.




fig 2.12: From the list, select your Four of Diamonds and click *OK*.




fig 2.13: Contact your Network Administrator to see which resources are available on **YOUR** machine. **Default resources (as shown) may not be available on your machine.**

- 13 - Windows will now copy your files. When prompted, click *Close* to continue.
- 14 - Windows will now prompt you to reboot your machine. Click *Yes* to reboot.
- 15 - Your Four of Diamonds is now installed. Contact your Network Administrator to configure your local LAN/Ethernet connections. You will need to restart your PC after this is set up.